


iLOQ S50 Quick Guide - Opening a lock with an iPhone


1 Open the screen lock

Note: Always keep your phone locked (unlock it using biometric ID, facial recognition, a PIN code or a pattern).



2

Open the iLOQ S50 mobile application




3

Press the lock icon in the middle of the screen.

Note: This screen also shows which locking system you have access to.

You should see a notification on the (half-white) screen: “Ready to Scan”



- 4 Place your phone next to the lock making sure that its **upper edge** touches the black knob of the lock.


Note: In all iPhones, the NFC antenna is always at the top of the phone



5

Keep your phone still until the screen shows: **Access Granted**. Now you can turn the black knob clockwise about half a turn.

Note: Sometimes the opening process may take a bit longer if some information needs to be updated at the same time.



4

What if the lock doesn't open?

A) Please, contact your key admin person to check that you have the needed access rights to open the lock in question.



B) The communication distance between the lock and phone is 0 – 20 mm, so you can even touch the lock with your phone.



C) You need an iPhone 7 or a newer model running iOS 13 or a newer release.



More information: support.iloq.com